

1. Copy RTPUSB.dll to a directory

(Example: D:\Your InstallSource)

2. Add the following into project.BIB (In the parameters tab)

MODULES(<== had exist in project.BIB)

RTPUSB.dll D:\Your InstallSource\RTPUSB.dll NK SH

FILES(<== had exist in project.BIB)

TPUtility.exe D:\Your InstallSource\TPUtility.exe NK

3. Add the following into project.reg (In the parameters tab)

[HKEY_LOCAL_MACHINE\Drivers\USB\LoadClients\7165_5768\Default\Default\UTPSTRM]

"DLL"="RTPUSB.DLL"

"Prefix"="UTP"

"Rotation"=dword:0

"DisableReport"=dword:0

"MouseMod"=dword:2

Note!

- a. DLL -- system uses and do'nt change
- b. MouseMod -- This parameter descripts the emulation mode of mouse
 - (1) desktop mode
 - (2) mouse mode
 - (3) button mode
- c. Rotation -- This parameter descripts the screen direction
- d. DisableReport -- This parameter inhibits touch panel to active mouse cursor
- e. Prefix -- Touch panel name. Don't change

4. TPUTility.exe is an tool to use it to do free draw test and 9 points calibration