

## QNX RS232 Driver Installation Note

Revision : 1.01.5608  
OS : QNX Neutrino RTOS v6.3  
Release Date : 08-08-2006

### File list:

TouchKit	- Utility
devi-eGalax	- RS232 Touch Screen Driver
input.localhost.txt	- Input Data
calib.localhost.txt	- Calibration Data

### Notes!:

**This Driver only support RS232.**

1. Copy "Touchkit" and "devi-eGalax" two files to '/usr/photon/bin' directory.
2. Change it's Permissions and make it Executable.
3. Open or Create "input.localhost" under '/etc/system/trap' and copy two lines to the file :  
kbf -d/dev/kbf ps2 mousedev  
devi-eGalax egalax fd -d/dev/ser1 abs

### Notes!:

support com2.

to the file : "ser1" it means only support com1.You can change it to "ser2" to

4. Open or Create "calib.localhost" under '/etc/system/trap' and copy the line  
0x0:1023x767:0 2047 0 2047 0